

Phone 1-574-642-3857
Fax 1-574-642-3858
<http://www.rctronics.com>

1-480700-0
Pin Insert End

Pin
Locating
RED-BLACK-VIOLET

PIN #3
PIN #2
PIN #1

White Only
Yellow Violet
Green Orange
Blue Black
Black White
Brown Brown
Grey Grey
White White

DAT-01345-14006 (6 INCH)

Mate-N-Loc operates relays Aux. #1 (Pin #1), Aux. #2 (Pin #2) and Heat (Pin #3) on Bus Power Center RCT-01507 with "IGNITION". Data Cable connects to PCB-01777-J3, Dash Switch Center.

Viewed with Tyco Connector
Plug-In Face Down.

Not Used
Black
Red

DAT-01345-03006

Mate-N-Loc Connector, Flat Face Down
2 Pin Part Number 1-480698-0

Diagram of the main panel showing various components and their connections. The panel is divided into sections for different functions: DOOR, DOME, VIDEO, READING, MIRROR HT, HEATER, AUX. 3, and LIFT SW. Each section has a set of relays (SW1-SW8) and a set of indicators (D1-D13). The panel is labeled with various part numbers and connector types. A red arrow points from the Tyco connector to the main panel diagram.

1-480700-0
Pin Insert End

Pin
Locating
RED-BLACK-VIOLET

PIN #3
PIN #2
PIN #1

White Only
Yellow Violet
Green Orange
Blue Black
Black White
Brown Brown
Grey Grey
White White

DAT-01345-14006 (6 INCH)

Mate-N-Loc operates relays Aux. #1 (Pin #1), Aux. #2 (Pin #2) and Heat (Pin #3) on Bus Power Center RCT-01507 with "IGNITION". Data Cable connects to PCB-01777-J3, Dash Switch Center.

Viewed with Tyco Connector
Plug-In Face Down.

Not Used
Black
Red

DAT-01345-03006

Mate-N-Loc Connector, Flat Face Down
2 Pin Part Number 1-480698-0

Diagram of the main panel showing various components and their connections. The panel is divided into sections for different functions: DOOR, DOME, VIDEO, READING, MIRROR HT, HEATER, AUX. 3, and LIFT SW. Each section has a set of relays (SW1-SW8) and a set of indicators (D1-D13). The panel is labeled with various part numbers and connector types. A red arrow points from the Tyco connector to the main panel diagram.