

Phone 1-574-642-3857
Fax 1-574-642-3858
<http://www.rctronics.com>

The image shows a control panel for a Global Emergency Vehicle (GEV). The panel features several buttons and status indicators. The top row includes an 'EMERGENCY MASTER' button (red) with a switch icon and code 'C-00020-03-0V1D', followed by a 'PRIMARY' button (black) with a 'P' icon and code 'C-10002-10-0V2D', and four 'NBL BLANK' buttons (black). The middle row shows status indicators: 'MASTER ON' (green), 'OPEN MODULE DOOR' (red), 'OPEN COMPT DOOR' (yellow), 'CHASSIS LOW VOLT' (red), and 'BATTERY' (green). The bottom row includes a 'MODULE MASTER' button (grey) with a switch icon and code 'C-00021-02-0V2D', followed by 'DOME LIGHT' (black) with a dome icon and code 'C-00023-00-0V1D', 'LEFT FLOOD' (black) with a left floodlight icon and code 'C-00045-00-0V1D', 'RIGHT FLOOD' (black) with a right floodlight icon and code 'C-00046-00-0V1D', 'REAR FLOOD' (black) with a rear floodlight icon and code 'C-00041-00-0V1D', a 'BACKUP' button (black) with a battery icon and code 'C-00042-10-0V0D', and a final 'NBL BLANK' button (black). The GEV logo is visible on the right side of the panel.

View A

RCT-02366 COMPLETE ASSY

RCT-02366-00001
DCL-00005-00004

4" T18R4C2

CTB75XNTA-C

STF-02377-00001
SUPERBRIGHT

103M
02377

DAT-01345-00010

01 Red 02 Black

Black Red 02 01

